



# Replacement OlyPocket 10 Batterie

OlyPocket electric agenda

Written By: Mohamed Mediouni



## INTRODUCTION

Replace the Battery of an electronic agenda.

## Step 1 — Batterie



- 1, Unscrew the back with a small philips screwdriver.
- 2, Place a CA-2032 battery into the back
- 3. Screw the cover back on

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-28 10:49:19 AM.